

# 3form graffiti removal instructions

## Graffiti Removal from 3form Materials

---

In the event that one of your 3form materials is subject to graffiti in the form of paint, permanent markers, or crayons, the following recommendations enable safe and easy removal. In the past, 3form has been asked to develop coatings or films to prevent graffiti. It has been found that these technologies only add additional cost and do not completely prevent graffiti. However, by relying on the excellent inherent chemical resistance of 3form materials, graffiti can be easily removed with a specialized cleanser. 3form specifies the use of That Orange Stuff™ and Tagaway® Graffiti removers because of their effectiveness and bio-friendly ingredients. That Orange Stuff safely and easily removes most types of graffiti from 3form Varia, Chroma, Glass, 100 PERCENT, and Koda XT materials. Tagaway is a more aggressive graffiti remover that can be used in the rare event that That Orange Stuff is not able to remove all graffiti. Tagaway should not be used on 3form Koda XT.

### That Orange Stuff Instructions

---

1. Mix That Orange Stuff with Water in a ratio of 1:12 (4 tbs per 3 cups water)
2. Shake mixture thoroughly
3. Liberally spray solution onto graffiti.
4. Let solution soak for 10 - 15 seconds.
5. Wipe graffiti away with a clean, soft, dry cloth.
6. Rinse thoroughly with clean water.
7. Repeat as needed.

\*\*\*That Orange Stuff is a concentrated formula. Always add That Orange Stuff to water before using. Using straight That Orange Stuff may cause damage to 3form panels.

### Additional Information

---

- Removes spray paints (enamel or latex), permanent marker, pen ink, paint pens, crayon, adhesives and more
- Works on painted surfaces, aluminum, glass, wood, plastics and more
- That Orange Stuff is environmentally friendly and biodegradable.
- Tagaway is a blend of biodegradable ingredients that is safe and effective in both hot and cold environments

Note: These recommendations are only applicable to 3form material surfaces that are not decorated with a 3form applied coating

For more information, contact 3form Product Technology at 801.649.2500.

### Tagaway Instructions

---

1. Liberally spray Tagaway onto graffiti.
2. Let Tagaway soak for 10 - 15 seconds.
3. Wipe graffiti away with a clean, soft, dry cloth.
4. Rinse thoroughly with clean water.
5. Repeat as needed.
6. Use soap and water to assure that no residual Tagaway is left on 3form Panel.

\*\*\*DO NOT allow Tagaway to soak on the panel for more than 30 seconds